

Aqua-Vu®

QUICK START GUIDE FOR: BITE LIGHT

1. Unscrew back to access batteries and power switch.
2. Requires 2 AA batteries (not included).
3. Use switch to toggle between High / Low / Off.
4. Replace back cover, do not over tighten. Overtightening will damage the O-Ring. **See Important note below.*
5. Aim light by pointing along an imaginary line at your lure.

*When securing the cap, tighten until the arrow is centered between the brackets. This will ensure the cap is properly fitted prior to placing in the water.

The Bite Light is waterproof rated to 75 feet



For helpful tips and FAQ's, visit our Online Help Center

Enter your model number (e.g., Bite Light) for helpful Video Tips and FAQ's on setting up and using your new Aqua-Vu Underwater Camera Adaptor System

www.aquavuhelp.com

