

Aqua-Vu[®]

MO-POD 3

CAMERA PANNING ACCESSORY



BATTERY PLACEMENT UNDER TOP CAP



WIRELESS REMOTE



ON/OFF TOGGLE SWITCH LOCATED ON THE UNDERSIDE

Aqua-Vu MO-POD 3 Quickstart Guide and FAQ's.

- 1) Remove top cap lid to battery compartment. Lid screws off counter clockwise.
- 2) Install 2 new AA batteries.
- 3) Replace lid.
- 4) Turn MO-POD 3 to On by toggle switch found on the underside of the MO-POD.
- 5) Adjust MO-POD 3 base legs to exceed size of hole.
- 6) Deploy camera to desired depth and secure cable to the S-Hook of MO-POD 3.
- 7) Use Wireless remote to pan the camera 360-degrees clockwise or counter clockwise.

FAQ & Trouble Shooting

Q: Can the MO-POD 3 be used with a 10-inch hole?

A: Yes, the legs will fold completely flat with loosening of the string.

Q: My MO-POD 3 will not turn?

A: Please double check the power switch and change the batteries.

Q: My MO-POD 3 still does not turn?

A: Your MO-POD 3 may need to be synced to the remote. Visit the link below and search MO-POD 3 for a video on this process.

Scan to visit our Video Resource Library for additional tips & instructional content.



www.aquavuhelp.com



STOP PLEASE READ BEFORE USING

Our Goal is 5 Star Service! If you should encounter difficulty using your Aqua-Vu MO-POD 3 or feel there may be something not working correctly, we are here to help. Before returning your MO-POD 3 or leaving negative feedback, please give us the opportunity to make things right at one of the methods below:

Call our support staff at: 866-755-6303 or

Chat with us live on our site: www.aquavu.com or

Review our Quickstart Guide/FAQ's for the MO-POD 3 on opposite side of card.

Aqua-Vu[®]



*Scan to visit our Video
Resource Library for additional
tips & instructional content.*



www.aquavuhelp.com

ONE YEAR LIMITED WARRANTY

Outdoors Insight, Inc. warrants its products to be free from defects in materials and workmanship for a period one-year from the original date of purchase. Outdoors Insight, Inc will at its sole discretion repair or replace any components that fail in normal use. Failures caused by abuse, misuse, alteration, or self-repair are not covered under warranty. The warranty is valid for the original owner and is non-transferable.

CUSTOMER SERVICE

We want our products to provide you with a pleasant on-the-water/ice experience. That means maximum customer satisfaction. If you have a problem with your Aqua-Vu unit please contact Outdoors Insight, Inc. Customer Service at one of the following methods:

PHYSICAL ADDRESS:

- Stop by during business hours 8am to 4pm M-F Central
- Our address is: 34076 County Road 3, Crosslake MN 56442

The Address for Returns is:

VIA USPS:

Outdoors Insight, Inc.
PO Box 368
Crosslake, MN 56442

VIA UPS/FEDEX:

Outdoors Insight, Inc.
34076 County Road 3
Crosslake, MN 56442